

WAXIE Select™ Sparkle Glass Cleaner



DESCRIPTION

Specially formulated for streak-free use on glass, mirrored surfaces, and more. Effective on highly reflective materials such as black metal filing cabinets, it can be used indoors and out, on hot or cold surfaces. It quickly dissolves smudge, film, scum, smear, bug residue and many other stubborn deposits. The “cleaning action” formula is virtually ammonia free (contains less than 0.02%) so as not to impart a strong lingering fragrance. The fast breaking white foam clings to vertical surfaces and is safe for use on window tinting, clear plastic, and other surfaces such as display cases and video displays, etc. Applications can be found in industrial and institutional settings, glass and mirror manufacturing, window installation, vehicle detailing, windshield replacement, marine/RV, and more.

SPECIFICATIONS

AS SOLD

| | |
|--|------------------------------------|
| Appearance..... | Aerosol containing a liquefied gas |
| Color..... | Colorless |
| Odor..... | Characteristic |
| pH..... | 9.0-10.0 |
| VOC..... | N/A |
| Melting Point/Freezing Point..... | No data available |
| Initial Boiling Point/Boiling Range..... | No data available |
| Flash Point..... | N/A |
| Flammability..... | Non-flammable aerosol |
| Relative Vapor Density..... | No data available |
| Density..... | No data available |
| Solubility(ies) / Water Solubility..... | No data available |
| Solubility in other Solvents..... | Not determined |
| Heat of Combustion..... | No data available |

ACTIVE INGREDIENT:

| | |
|-------------|------------|
| Butane..... | ≥ 1 - < 5% |
|-------------|------------|

SHELF LIFE: All WAXIE brand chemical products have a guaranteed shelf life of up to one year after the date product was manufactured, when stored in ambient conditions. The actual manufacturing date is included in a date code on every product container.

DIRECTIONS FOR USE

Not for use in food contact applications. **IMPORTANT:** Always shake well before using and periodically during consistent or heavy use. Remove cap and rotate actuator to point toward the painted dot on the valve cup. Hold can upright four to six inches from surface to be cleaned. Spray sparingly then clean with a soft, commercial grade, paper or cloth wiper. Turn wiper over and polish immediately or use a separate dry wiper to assure a clean and streak-free surface. Rinse with portable water when used in food processing areas. **ATTENTION:** Never use inverted, sideways, or at an angle less than 45 degrees to a horizontal surface.

DILUTION RATIO: Ready-to-use.

Item: 950152 16 oz 12/cs

APPLICATION



FEATURES & BENEFITS

- Professional-strength
- 98% VOC free
- Unique designed cap provides source reduction of 75% compared to other caps
- Boxes contain 45% post-consumer recycled material
- Can is tin-free; 100% recyclable
- Can contains 50% recycled steel from post-consumer recycled waste
- Ready biodegradable using ASTM E1720-01 test method
- No CFC's; No alcohol
- Safe on plastics & video displays

PRODUCT REGISTRATIONS & CERTIFICATIONS

- RespirTek Certified for Biodegradability
- NSF A1+C1 Certified

WAXIE Select™ Sparkle Glass Cleaner

SAFETY INFORMATION

PERSONAL PROTECTIVE EQUIPMENT:

Ready-to-Use B – Safety Glasses & Gloves



Read the Safety Data Sheet (SDS) and product label before use. The SDS and product label contain hazard warnings, precautionary statements and first aid procedures. SDS documents are available online at www.waxie.com or by calling (800) 995-4466.

For sale to, use and storage by service professionals only. Keep out of reach of children.

HOTLINE NUMBER: You may contact Chem-Tel at (800) 255-3924 for emergency medical treatment information.